

Lite-Shield™

Spreader & Accessories



LITE-SHIELD™ STRUTS

Scew-jack type spreaders

LITE-SHIELD™ 24 STRUTS			
Adjustment Range (Inside Panel Dimension)			
Model	Weight (lbs.)	W/ Connector	W/O Connector
24LSS-1	12	24" - 32"	20" - 28"
24LSS-2	16	32" - 48"	28" - 44"
24LSS-2.5	21	40" - 64"	30" - 60"
24LSS-3	25	51" - 86"	47" - 82"

The screw jack strut features a shallow square thread design and is coated with a special rust inhibitor which wipes clean with a rag, for smoother performance.



STRUTS

LITE-SHIELD™ PULLBAR

Adjustable Excavator Pull Bar

LITE-SHIELD™ 24 PULLBAR		
Model	Weight (lbs.)	Range
24LSPB1	24	24" - 32"
24LSPB2	32	32" - 48"
24LSPB2.5	38	40" - 64"
24LSPB3	53	51" - 86"

Pullbars are intended to aid the backhoe operator in positioning the Lite-Shield™ in the trench, as well as to pull the aluminum shield forward by using the excavator bucket to pull on the Pullbars, not the struts.



PULLBAR



KNIFE-EDGE

Knife edges make the Lite-Shield™ much more effective when digging in soft, wet, silty or sandy material. Available on 6', 8', 10' and 12' panels.



TOP CAP

The extruded T-6 Top Cap option provides a protective wear bar for the top panel. Available on 6', 8', 10', and 12' panels.